

Maintenance & Care of Bamboo Floors:

As with any solid wood or pre-finished product, maintenance is crucial to the longevity and appearance of your bamboo floors!

CLEANING INSTRUCTIONS:

On a daily to weekly basis:

1. Vacuum or sweep with a soft bristle broom and where possible, sweep in the direction of the length of the planks.
2. If vacuuming, do not use a vacuum that has a beater bar, metal wheels, and/or metal or hard plastic attachments. Best to use felt or fine brush attachments. Make sure plastic wheels are free of dirt prior to vacuuming.

On a monthly basis or as needed:

1. Soft bristle broom / vacuum as directed above.
2. Take an empty spray bottle fill it with 3/4 water and 1/4 white vinegar. Spray that mixture onto a microfibre mop to dampen it, rather don't spray directly onto the floor itself and clean with a few strokes, in the length of the floor.

Preventive Maintenance:

- » Do not wax
- » Use protective mats at doorways, as gritty sand and dirt are abrasive to bamboo floors.
- » Install furniture pads on all furniture legs, especially if it has the potential of moving on the bamboo. Make sure you use the correct size and pad thickness for the weight of the furniture.
- » Clean and replace these felt pads yearly, or sooner if they are thinning out or damaged.
- » Use rugs (non rubber-back) in high traffic areas.
- » Keep floors clean and free of dirt & sand.
- » Wipe up spills immediately.